

# THANK YOU!

We want to start by thanking you for your confidence in choosing our food transport box for your needs. We are convinced that you will be satisfied!



Anders Pettersson, CEO

## GET STARTED

### ||| KEEPING HOT

- 1** Insert the electric plug in a socket.
- 2** The heating element will immediately start heating the box to 80 °C (factory value). You can see the current temperature directly on the display. When the temperature reaches 80 °C, the heating element switch off and will start again when the temperature has dropped to 79 °C.
- 3** Wait at least **15 minutes (F)** or **60 minutes (E)** so that the box has time to get evenly hot.

#### **4** LOADING FOOD IN THE THERMOBOX



Food must be well **heated** before it is placed in the box.

Load the canteens **starting from the top.**  
(Feel free to use canteen lids to avoid spillage.)

#### **5** UNLOADING FOOD FROM THE THERMOBOX



Unload the canteens **starting from the bottom.**

### \* KEEPING COLD

- 1** Insert the electric plug in a socket.
- 2** The cooling unit will immediately start cooling the box to 3°C (factory value). You can follow the current temperature directly on the display. When the temperature reaches 3°C, the cooling unit stops and then starts again when the temperature has risen to 5°C.
- 3** Wait at least **25 minutes (K)** or **45 minutes (C)** so that the box has time to get evenly cold.

#### **4** LOADING FOOD IN THE THERMOBOX



Food must be well **cooled** before it is placed in the box.

Load the canteens **starting from the bottom.**  
(Feel free to use canteen lids to avoid spillage.)

#### **5** UNLOADING FOOD FROM THE THERMOBOX



Unload the canteens **starting from the top.**

# SETTINGS

If necessary, the temperature of the box can be adjusted. This is done through the display in the front.



## CHANGE TEMPERATURE (SET VALUE)

- 1** Hold down the "Set" button.
- 2** The set value is now shown flashing in the display. Use up/down arrow to adjust the value.
- 3** Confirm the setting by shortly pressing the "Set" button again.

## MAINTENANCE

Observe the instructions below to minimize service and repairs:

- Never pull the cord when disconnecting, pull the plug.
- Check continuously door hinges, door seals, wheels and brakes.

## CLEANING

Cleaning the transport box is very easy due to the pressed stainless steel guides.

Please observe the following:

- Never use a high-pressure cleaner for cleaning.
- Use only mild detergent (pH 6-8).
- Use only plastic scraper for cleaning inside the box.

*Keeping the right temperature*